

# POLYLAST™

## BUNKER LINER INSTALLATION GUIDE

Polylast Bunker Liners are prefabricated and delivered ready to lay, it only requires placement of the preformed pads, the seams of which may be stapled and glued together. From start to finish, bunkers of 1,000 sq. ft. or more can be installed, and ready for sand and play in about an hour.

**1** Remove sand from the bunker.



**2** Lift the edge of the turf around the bunker if turf goes to bunker edge/liner intercept. If turf is not yet in place, staple bunker liner in place and lay turf over the bunker liner later.



**3** Starting from the middle of the bunker, unroll the pads and lay them so the edges touch but do not overlap. If necessary, cut pads to fit in shorter runs or to lay end to end for longer runs. Staple and / or glue ends together.



**4** Place the edges of the pads under the turf that was lifted up in step 2. Cut to size and shape as needed. Replace turf over pad edges.



**5** Replace the sand. The bunker is now ready for play.



7432 E Tierra Buena Ln. Suite 105  
Scottsdale, AZ 85260

Phone | (480) 998-3033  
Email | [Info@PolylastSystems.com](mailto:Info@PolylastSystems.com)

[www.PolylastSystems.com/Golf-Course](http://www.PolylastSystems.com/Golf-Course)

Polylast Systems Patent No.: US 8,389,624 B2 issued March 5, 2013